

WÜNDER

USER MANUAL
THE RING

Warm, welcoming, and built to gather people around fire. The Ring is a rough beauty with a sweltering hot heart. Its curved shape with vents between the slats providing extra oxygen for the fire, makes a good, hefty flame and little to no smoke.
Tout feu tout flamme, quoi.

SPECIFICATIONS

- Corten steel
- Heat resistant powder coated steel (Olive green version only)
- Including adjustable feet
- Including ash tray

DIMENSIONS

	DIAMETER	HEIGHT	WEIGHT
CORTEN | 106	106 CM	35 CM	± 60 KG
OLIVE GREEN | 106	106 CM	35 CM	± 60 KG
CORTEN | 58	58 CM	45 CM	± 45 KG

IMPORTANT NOTES

- The Ring is made of Corten steel. During its first few weeks of use, it undergoes a natural oxidation process that will cause temporary rust runoff on the surface below. Exercise extra caution if placing The Ring on sensitive, light-colored, or porous materials. Once the steel fully matures and completes its oxidation process, the staining will cease.
- The Ring produces real fire and extreme heat. Always place it on a stable, heat-resistant, non-combustible surface. Keep a safe distance between the fire pit and any surrounding structures, plants, or flammable materials. Never leave a lit fire pit unattended.
- The 106 cm model is equipped with a removable ash tray. Always keep the ash tray positioned underneath The Ring during use.

CONTACT

Questions, comments or suggestions relating to a product on our website? Feel free to get in touch with us!

Wünder — Sasstraat 5, 8870 Izegem, Belgium
+32 51 79 17 31 — info@wunder.be

CORTEN STEEL

Exposed to the weather, Corten steel takes on a life of its own. Inevitable rainfall and other precipitation will ignite a rusty oxidation layer to form, protecting it against further corrosion. The natural formation of this barrier can take up to 1 year.

At the beginning of this process, this can cause The Ring to leave stains on the surface underneath. The risk of marks decreases over the course of just a few weeks. Rust stains can easily be washed away with a surface specific rust remover and some scrubbing.

MAINTENANCE

Because of the rusting process, the inner bowl creates its own protection layer and doesn't need much maintenance. To make The Ring last longer, it's advised to:

- Remove the ash remains after every campfire session.
- Remove any fallen leaves or dirt.
- Remove stagnant water to prevent damage.
- Brush off The Ring if necessary with a hard brush and clean water.
- Place The Ring in an open area during winter to help it dry faster and reduce the accumulation of leaves and debris. For additional protection, a cover plate for The Ring is available separately.

POWDERCOATED STEEL
(OLIVE GREEN VERSION ONLY)

The Powder coating used for The Ring is specifically developed to protect surfaces exposed to extreme high temperatures. The scratch and chip resistant characteristics of the coating will protect The Ring for years to come.

Abundant heat can cause the coating to turn darker and become soft thus more sensitive to scratches. Remove burning logs on the outer ring immediately.

MAINTENANCE

- Clean with warm water and a sponge.
- Use non-abrasive soap for stubborn stains. Do not use an abrasive sponge but soft sponge or wipe.
- Minor damage can be touched up with a paint pen in the same RAL color. (Contact Wünder for more details.)
- Do not use a pressure washer to clean The Ring. This will only damage the product.

CONTACT

Questions, comments or suggestions
relating to a product on our website?
Feel free to get in touch with us!

Wünder — Sasstraat 5, 8870 Izegem, Belgium
+32 51 79 17 31 — info@wunder.be



DURING USE

Supervise the fire continuously. Seat guests at least 2 meters (6.5 ft) away in non-flammable chairs. Do not wear loose clothing or flammable materials such as nylon or synthetic fabrics. Keep the fire low and controlled - maximum flame height: 60 cm (24"). Add or adjust wood gradually to maintain airflow. Never move burning logs. If the ground or surrounding grass is dry, lightly wet the area before use. Extinguish the fire immediately if:

- “wind conditions increase,”
- “clothing catches fire,”
- “or the fire spreads uncontrollably.”

AFTER USE

Fully extinguish: let burn to ash → drown with water → stir/shovel coals → repeat until no steam, hissing, or heat (hand test above ashes). Dispose cool ashes in metal container, away from flammables - do not reuse until cold. Cover only completely cool to prevent reignition.

GENERAL

Inspect before each use for cracks, stability, or damage - discontinue if compromised. Keep away from low branches/dry grass. Not for cooking unless specified. Follow all local ordinances. Misuse voids warranty and risks liability. Adult supervision required.

CONTACT

Questions, comments or suggestions
relating to a product on our website?
Feel free to get in touch with us!

Wünder — Sasstraat 5, 8870 Izegem, Belgium
+32 51 79 17 31 — info@wunder.be

CRITICAL FIRE-STARTING RULES

Use only dry, seasoned hardwood (no softwoods that pop and spark). Never use gasoline, kerosene, diesel, lighter fluid, alcohol or any accelerants - explosion/flame jetting hazard.

Build the fire in the center of The Ring using this sequence: tinder → kindling teepee → small logs → larger logs. Light with long match/lighter from outside. Never leave fire unattended, even for a minute. Keep a charged fire extinguisher (ABC type), garden hose, bucket or water/shovel immediately adjacent.

DANGER: EXTREME HEAT HAZARD

The Ring fire pit and surrounding surfaces become extremely hot during use and remain dangerously hot for many hours afterward. Never touch the fire bowl, legs, or ash tray while in use or until fully cooled (minimum 12 hours). Severe burns can occur in seconds. Keep children, pets, and flammable materials at least 2 meters (6.5 ft) away at all times.

WARNING: FIRE AND BURN RISK

For outdoor use only. Never use indoors, in garages, tents, or enclosed space — srisk of deadly carbon monoxide poisoning. Place on a stable, level, non-combustible surface such as concrete, stone, gravel, or packed dirt. Maintain a minimum 2 meters (6.5 feet) clearance required from decks, fences, trees, overhangs, awnings, power lines, or any combustible materials. Check and comply with local fire codes, burn bans, and restrictions (varies by city/state). Do not use on wooden decks without a fire-resistant mat. Always use a spark screen if available during operation to contain embers.

WARNING: PROPOSITION 65 (CALIFORNIA RESIDENTS)

This product can expose you to chemicals including carbon monoxide, soot, and polycyclic aromatic hydrocarbons (PAHs), which are known to the State of California to cause cancer and birth defects or other reproductive harm.
For more information go to www.P65Warnings.ca.gov



CONTACT

Questions, comments or suggestions relating to a product on our website? Feel free to get in touch with us!

Wünder — Sasstraat 5, 8870 Izegem, Belgium
+32 51 79 17 31 — info@wunder.be

